# GLOSSY GLOM

AURORA MOON 360

# USER MANUAL



## **Technical Data**

Model SM207

Input power 110V/240V 50HZ/60HZ

Output power 40W

Adjustment range 0%~100%

**CCT** 2700K~5600K

CRI RA>95


Lumen 1600LM

Lifespan 50000H

**Size** 680\*262\*70 MM

Weight 8 KG

## Detail




# Assembly Instructions



#### **CONNECT THE POWER CABLE**


FEED THE POWER CABLE DOWN THE TUBE AND TAKE IT OUT FROM THE BASE SIDE OF THE STAND.



#### **CONNECT THE STAND AND LAMP**


RELEASE THE LOCK KNOB AND TAKE OUT THE FLEXIBLE STAND PART B
FROM PART C.

ROTATE STAND PART B TO CONNECT IT WITH STAND PART A, AND THEN TIGHTEN THE LOCK KNOB.



#### ASSEMBLE THE BASE

FEED THE POWER CABLE DOWN INTO THE BIG HOLE ON THE BASE. ATTACH
THE POLE ASSEMBLY TO THE BASE USING 3PCS M5 HEXAGON SOCKET HEAD
CAP



#### **CONNECT THE CABLE WITH ADAPTER**

L CONNECT THE CABLE WITH THE ADAPTER DC PORT, AND PLUG THE POWER ADAPTER AC SIDE INTO LIGHT POWER.


## ADJUSTMENT INSTRUCTION

#### **POWER ADJUSTMENT**

PRESS THE SWITCH KNOB
TO TURN ON THE POWER
SWITCH. THE POWER CAN BE
ADJUSTED STEP BY STEP
FROM 1% TO 100%,
INCREASING CLOCKWISE
AND DECREASING STEP BY
STEP IN THE
COUNTERCLOCKWISE
DIRECTION. EACH TOGGLE
BUTTON CHANGES BY 1%.

#### **CCT ADJUSTMENT**

THE COLOR TEMPERATURE
CAN BE ADJUSTED FROM
2700K TO 5600K, GRADUALLY
INCREASING IN THE
CLOCKWISE DIRECTION,
DECREASING IN THE
COUNTERCLOCKWISE
DIRECTION, AND CHANGING
THE TOGGLE BUTTON BY
100K.




# Packing list

NO.	Name	Quantity
1	Moon Light	1pc
2	Adapter	1pc
3	AC charger power line	1рс
4	Manual	1рс
5	Stand	1рс
6	Base	1рс
7	Cellphone holder	1pc
8	Tool kit (socket wrench 1pc, Hexagon socket head cap screws 3pcs)	1set



## Notes





1	Please set the lamp and base on same direction for safe use.
2	Please do not hang any heavy items on the lamp when it works.
3	Please do not place the light in a high temperature and humidity.
4	Please do not touch the light by hand. Do not immerse the product in water or expose it to rain.

### After sales service

- 1) Do not disassemble or repair this product by yourself.
- 2) Touch the product's internal part could result in injury. In the event of malfunction, please turn off the power, unplug the power cord and contact the supplier in time.
  - 3) The warranty for the light with the invoice from the date of sale is one year.
- 4) Glossy Glow defect must be returned in original shipment packaging, Glossy Hub PTY LTD will not accept glossy glow via courier under any other circumstances.

  Drop off is available if the original box has been discarded.

\*The technical are subject to change, the final interpretation of the right to belong to the company